
CT-54 AUTOMATIC DOOR BOTTOM INSTRUCTIONS

DROP

7/16 in



HOLLOW METAL DOOR AUTOMATIC DOOR BOTTOMS





ILLUSTRATED


WITH NO SHIM





FULL MORTISED: CUT TO FIT INSIDE WIDTH OF THE DOOR LESS 1/16".






HOW TO INSTALL:

SEE ABOVE RIGHT FOR THE AUTOMATIC DOOR BOTTOM LENGTHS BASED ON MORTISED APPLICATIONS. THE ADJUSTING NUT/PLUNGER MUST BE INSTALLED ON THE HINGE SIDE OF THE DOOR FOR ALL MOUNTING APPLICATIONS.

SEE DETAIL 'A' FOR HOLE LOCATION IN EDGE OF DOOR TO PERMIT PLUNGER TO STRIKE DOOR FRAME.

FINAL ADJUSTMENT:

TURN ADJUSTING NUT COUNTERCLOCKWISE OR CLOCKWISE, AS PER ABOVE LEFT, TO ENSURE SEAL MAKES CONTACT WITH SILL/FLOOR. A FULLY COMPRESSED SEAL IS NOT RECOMMENDED, NOR IS IT NECESSARY AND WILL INHIBIT PROPER OPERATION. SEAL SHOULD SIMPLY MAKE CONTACT WITH SILL/FLOOR.





K.N. CROWDER MFG. INC.

1220 BURLOAK DRIVE BURLINGTON, ONTARIO, CANADA, L7L 6B3 TELEPHONE: 905-315-9788 - FAX: 905-315-8090 TOLL FREE PHONE: 1-866-999-1KNC (1562) TOLL FREE FAX: 1-800-567-0123

K.N. CROWDER INC.

210 EIGHTH STREET SOUTH LEWISTON, NEW YORK, U.S.A. 14092 TELEPHONE: 1-716-754-8247 TOLL FREE FAX: 1-800-567-0123

EXTENDED FULLY TO THE LOCK SIDE. BEFORE TRIMMING