




FE575/FE595 Door Preparation Instructions

For Door With No Holes


Tools Needed



Drill Bits Needed:
1/8", 7/8", 1"



2 1/8" Hole Saw




Pencil




Chisel

1 Measure Door Width


If the door is thinner than 1 1/8" or thicker than 1 3/4", then the lock will not fit properly on the door.





2 Mark Lock Centerline on Door Face and Door Edge



3 Mark and Drill Hole in Door Face with 2 1/8" Hole Saw




4 Mark and Drill Hole in Door Edge



5


If Necessary, Mortise for Latch

- Insert latch into door edge hole.
- Use pencil to trace latch and mark holes.
- Remove latch and drill two $\frac{1}{8}$ " pilot holes.
- Use chisel to create latch mortise.

**7**

Mark and Drills Holes for Strike

- Measure 38" from finished floor and mark on door jamb.
- Mark center for strike hole exactly opposite latch hole.
- Drill 1" hole, $\frac{1}{2}$ " deep.
- Line up strike with hole in door jamb.
- Use pencil to trace strike and mark holes.
- Drill two $\frac{1}{8}$ " pilot holes and use chisel to create strike mortise.

**6**

Measure Door Jamb for Strike

